Powering the Nation Since 1936



MODEL	3 PHASE	2 PHASE	1 PHASE	WEIGHT	DIMENSIONS (LxWxH)
TRACTORPACK-050	50kVA	30kVA	30kVA	330kg	95x45x85cm
TRACTORPACK-060	60kVA	40kVA	40kVA	360kg	95x45x85cm
TRACTORPACK-085	85kVA	50kVA	50kVA	420kg	105x45x70cm
TRACTORPACK-100	100kVA	67kVA	67kVA	470kg	105x55x80cm



SPECIFICATIONS

FREOUENCY **ALTERNATOR SPEED GEAR BOX**

50Hz 4-Pole, 1500rpm Fitted with splined shaft for approximate input speed of 500rpm.

PTO Driven Alternators

Tractor pacs are power-take-off driven alternators that couple to most brands of tractors.

Dunlite Tractor Pacs are especially designed to run from the back of a tractor to back-up Dairies during down times, making them perfect for rural power applications. Convenient and sturdy, Tractor Pacs are a necessity for farmers wanting to protect their investment and peace-of-mind.

OPTIONAL EXTRA

MODEL DESCRIPTION

DIGITAL METER BOX PTO Digital Output Module, displays Amps, Volts, Frequency * Supplied loose for installation on site

Specifications and product availability subject to variation without notice. Updated 04/05/2022

Victoria: Head Office 59 Export Drive Brooklyn VIC 3012 P: +61 3 9316 9799 F: +61 3 9314 0909 E: dunlite@wellcross.com.au **New South Wales** Unit 2/1040 Canley Vale Road Wetherill Park NSW 2164 P: +61 2 9757 5800 F: +61 2 9757 5899 E: nsw@wellcross.com.au

Queensland Unit 2/55 Christensen Rd Stapylton QLD 4207 P: +617 3386 2400 F: +61 7 3386 1241 E: qld@wellcross.com.au **North Queensland**

Unit 19/547 Industry Park 547-593 Woolcock St Mount Louisa, Townsville, QLD 4814 P: +61 7 4774 6331 E: nthqld@wellcross.com.au

Western Australia Unit 8/235 Camboon Road Malaga WA 6090 P: +618 9248 2955 F: +61 8 9248 2933 E: wa@wellcross.com.au

South Australia Ph: 0417 592 530 E: bnicholas@wellcross.com.au

dunlite.com.au

1300 555 253